System Firmware Update Instruction

- System firmware update is provided available to provide additional features or fix certain issues that may affect an individual system. Please DO NOT apply this update unless it is necessary.
- Firmware updates should not be applied to any other than corresponding Vinpower models. Please consult with Vinpower Digital for compatibility.
- Files are generally zipped. Place the .zip file into its own directory and then use an extraction utility such as WinZip. http://www.winzip.com/
- Vinpower Digital will ONLY support the use of firmware that has been obtained from
 Vinpower Digital such as this one. The use of any Non-Vinpower firmware will invalidate
 your warranty.

In order to perform the update, you will need a System Update USB/SD Device.

- To create a System Update USB/SD Device utilizing the binary Update Core File provided by Vinpower Digital:
 - 1. Extract the core update file(s) to your desktop from the zip archive.
 - 2. Transfer those update file(s) into an standard USB/SD device's root folder.
 - 1. (Note: Such device needs to be preformatted as FAT/FAT32 file system.)
 - 2. Insert the System Update USB/SD Device into the "Source" port of the USB/SD Duplicator.
 - 3. Go to "Utilities" -> "Update Firmware"
 - 4. Press "ENT" key to perform the update.
 - 5. Once completed, restart the system when asked to do so.